

# CARE AND HANDLING



10000 Iota Dr.  
San Antonio, TX, 78217  
(210) 590-6100

# MSA INFORMATION DOCUMENT

**SUBJECT: ACCORDIA® Window Shade System Cleaning and Maintenance**

## CLEANING INSTRUCTIONS (INNER AND OUTER LENS)

The Inner lens has a scratch resistant finish. Because of this material's surface, avoid the use of abrasive cleaners and/or cleaning implements that may mar or gouge the coating.

## CLEANING TO MINIMIZE SCRATCHING

Moisten soft, non-abrasive lint free cloth sparingly with *Glass Plus* or compatible cleaner. Apply moistened cloth to lens. This will minimize liquid accumulation on the lens surface. Excess liquid may otherwise enter the frame lens seal and cause water spotting to the mask. Dry thoroughly with a chamois or moist cellulose sponge to prevent water spots.

### **Some Important “DON'TS”:**

1. **DO NOT** spray or apply cleaner directly to lens, to avoid cleaner over spray getting on other components of the shade, or liquid seeping under the seals.
2. **DO NOT** clean in hot sun or at elevated temperatures.
3. **DO NOT** use abrasive or highly alkaline cleaners on lenses.
4. **DO NOT** use caustic solutions such as benzene, gasoline, acetone, M.E.K. or carbon tetrachloride on lens. Although several **commercially available** cleaning agents such as *Windex or Glass Plus* are accepted for cleaning **Lexan lenses**, any cleaner containing ammonia could be harmful to customer-plated frames, which sometimes have a clear coat. Care should be taken in this case.



10000 Iota Dr.  
San Antonio, TX, 78217  
(210) 590-6100